



AQUAFLOW PROFIT TRAP FITTING INSTRUCTION

Trap inlet

When connecting the Trap Inlet to the Waste Outlet, it is important to ensure that a proper 'seating' is obtained and it is therefore recommended that the Waste Outlet used be to British Standard or equivalent, otherwise difficulty may be experienced in obtaining a water tight joint. All Traps are supplied complete with inlet washers. Connect Trap Inlet Nut to waste outlet and hand tighten. A tool can be used but do not over tighten.

Trap with Multifit Outlet

For use with plastic pipes to BS EN 1451-1:2000 and BS EN 1329-1:2000, copper pipe (metric or imperial) and lead pipe. Fit as follows:

- Chamfer inside of pipe, if necessary to remove any burr and to enable plastic pipe to be eased over internal sleeve
- Remove nut, plastic friction washer and rubber olive from Trap
- Push nut, plastic friction washer and rubber olive over pipe
- Push pipe over Internal Sleeve and into Trap
- Connect nut and hand tighten

If a plastic pipe is undersize, or out of shape, the end may require to be warmed to enable it to be pushed over the Internal Sleeve and into the Trap. A few rotations of the pipe in the palm of a hand should be sufficient warmth A few rotations of the pipe in the palm of a hand should be sufficient warmth

Traps with Universal Outlets

Fit as Multifit but Internal Sleeve not applicable

MULTIFIT FITTING INSTALLATION INSTRUCTIONS

Multifit Fitting

For use with plastic pipes to BS EN 1451-1:2000 and BS EN 1329-1:2000, copper pipe (metric or imperial) and lead pipe. Fit as follows:

- Chamfer inside of pipe if necessary to remove any burr and to enable plastic pipe to be eased over internal sleeve
- Remove nut, plastic friction washer and rubber olive from Fitting
- Push nut, plastic friction washer and rubber olive over pipe
- Push pipe over Internal Sleeve and into Fitting
- Connect nut and hand tighten



If a plastic pipe is undersize, or out of shape, the end may require to be warmed to enable it to be pushed over the Internal Sleeve and into the Fitting. A few rotations of the pipe in the palm of a hand should be sufficient warmth

Universal Fittings

Fit as Multifit but Internal Sleeve not applicable

SUREFIT FITTING INSTALLATION INSTRUCTIONS

Surefit Fitting

For use with McAlpine HDPE plastic waste pipe manufactured to BS EN 1329-1:2000 only. Fit as follows:

- Chamfer inside of pipe if necessary to remove any burr
- Remove nut and rubber washer from Fitting
- Push nut and rubber washer over pipe
- Push pipe into socket
- Connect nut and hand tighten